

SUPER LUBE® GREASE COMPATIBILITY

For reference only

Testing is the only way to verify compatibility

Compatible	Borderline	Incompatible	Not Determined
Aluminum Complex	Calcium Sulfonate	Calcium Complex	Barium Complex
Barium Soap		Sodium Soap	Calcium Stearate
Bentone (clay)			Calcium 12 Hydroxy
Lithium Stearate			
Lithium Complex			
Polyurea			

In addition to the various thickening agents, base oils and additives affect grease compatibility.

It is recommended that grease components be flushed clear of any old grease wherever possible. If this is not practical, purge out as much of the old grease as possible. Repeat within a short period of time and monitor for compatibility issues.